

BRITPART FITTING INSTRUCTIONS

The quality parts for Land Rovers

Defender Rear Wheel Arches

Part Number - DA1978



Remove original arch. Sit new arch in place. Line up holes. Fix new arch in place. Starting from centre top working your way down either side.



Britpart

The Grove, Craven Arms,
Shropshire, SY7 8DA United Kingdom
www.britpart.com

VR. 1.

Disclaimer

These fitting instructions are intended for general guidance only. No responsibility will be accepted for damage to persons, property, equipment or vehicles caused during or arising from the fitting or using of this product. Fitting this item to your vehicle may constitute a vehicle modification and therefore we strongly recommend that you check the product complies with local laws and legislation and always inform the vehicle's insurance company accordingly.